






**ROLHORDEUR
MOUSTIQUAIRE
ENROULABLE PORTE
ROLLER SCREEN DOOR**



**Handleiding
Guide d'installation
Manual**

STD



TOOLS



Ph 2



Ø3, Ø4 mm



(3 mm) **A**



3,5x16 mm (2x) **C**




(2x) **B**



(2x) **D**



1x




1x




2x


G






E 2x





F








3



4




5




6a

(ENKELE DEUR I PORTE SIMPLE / SINGLE DOOR)




6b


(DUBBELE DEUR I PORTE DOUBLE / DOUBLE DOOR)




7




8






9




10






16




17




Service

123100450



123100451



123100452



123100454

